

# SAFEAWAKE BED SHAKER INSTALLATION & OPERATION GUIDE

INST-SABS 9V 1.0

# SAFEAWAKE

Model # SABS 9V 1.0

Electrical Rating: 9 VDC, 1.5 A max

SafeAwake, LLC  
8940 Old Annapolis Rd Suite J  
Columbia, MD 21045

The SAFEAWAKE bed shaker is designed *ONLY* for use with the SAFEAWAKE unit model # SART 9V 1.0

It is important to read the following instructions before installing and operating the SAFEAWAKE Bed Shaker. It is recommended to read the SafeAwake Installation & Operation Guide (INST-SART 9V 1.0) to understand how to operate the SAFEAWAKE unit. The SAFEAWAKE Bed Shaker is a key component of the SAFEAWAKE safety device and its proper use is essential in providing the intended protection.

## PURPOSE, LIMITATIONS AND GENERAL SAFETY INFORMATION

The SAFEAWAKE is a supplemental fire safety device that helps alert you when your smoke alarm is sounding. When your smoke alarm sounds, the SAFEAWAKE activates a vibrating bed shaker, a low frequency sounder, and a flashing light to alert you. These supplemental alerts are particularly of assistance to those with hearing impairments who may have a hard time hearing a conventional smoke alarm. In order to provide the intended supplemental alerts, the SAFEAWAKE bed shaker must be connected to the SAFEAWAKE device and the bed shaker must be installed under the mattress.

- The SAFEAWAKE will not be as effective in awakening a person from sleep if the person is not sleeping in the bed where the bed shaker has been installed. The bed shaker is particularly important in awakening those with hearing impairments. The low frequency sounder will aid those with high frequency hearing loss and the flashing light is intended to alert you if you are awake.

## RECOMMENDED LOCATION / MOUNTING

### **⚠ WARNING**

- The bed shaker may not perform adequately when used with waterbeds or other vibration-dampening

mattresses. Be sure to test the bed shaker with your mattress to ensure adequate vibration.

The sensor unit can be placed on a nightstand or mounted to the wall. The bed shaker can be installed between the mattress and box spring of your bed. Select a location for the SAFEAWAKE unit that is adjacent to your bed, within reach of an electrical receptacle, and close enough to connect the motorized bed shaker when installed under the mattress.

The back panel of the SAFEAWAKE has two mounting keyholes that allow the unit to be wall-mounted using two (2) wallboard anchors and screws (not supplied).

## SET-UP

1. Connect the bed shaker adapter cord onto its pin located on the right-hand side of the back panel of the SAFEAWAKE unit and feed the cord through its open J-slot in the cover.
2. Place the SAFEAWAKE unit on your nightstand or mount on adjacent wall.
3. Place the bed shaker disk **BETWEEN** the mattress and box spring of your bed, preferably directly beneath your sleeping position. Periodically check the location of the bed shaker as it may move over time.
4. Once the SAFEAWAKE is correctly powered, the GREEN indicator light on the front of the SAFEAWAKE will illuminate.
5. Check smoke alarm batteries and test all smoke alarms to ensure your smoke alarm is fully operational.
6. Depress the smoke alarm button for at least thirty seconds or until the SafeAwake captures the alarm signal. The SAFEAWAKE is equipped with a low frequency sounder, a flashing light, and a bed shaker to notify you that the smoke alarm is sounding. Ensure that each of these notification alarms is working and that you can feel the bed shaker vibrating your mattress.
7. Your SAFEAWAKE is now in operation!